videorecdctdisp

March 8, 2017

1 Videorecdctdisp

Program to capture a video from the default camera (0), compute the 2D DCT Type 2 on the Green component, take the magnitude (phase) and display it live on the screen

```
-Gerald Schuller, Nov. 2014
```

• Import relevant modules:

• Instantiate capturing object:

```
In [ ]: cap = cv2.VideoCapture(0)
```

- Start capturing and apply 2D-DCT on each of the frames and display the 2D-DCT for the live capture:
- Press 'q' to quit the popped up windows:

```
In []: while(True):
# Capture frame-by-frame
[retval, frame] = cap.read()
print(frame.shape)
#compute magnitude of 2D DCT of green component
#by applying the DCT first along the rows and the along the columns,
#with suitable normalization for the display:
frame=sft.dct(frame[:,:,1]/255.0,axis=1,norm='ortho')
frame=np.abs(sft.dct(frame,axis=0,norm='ortho'))
#angle/phase:
\#frame = (3.14 + np.angle(np.fft.fft2(frame[:,:,1]/255.0)))/6.28
# Display the resulting frame
cv2.imshow('Betrag der 2D - DCT Typ 2 des Videos',frame)
#Keep window open until key 'q' is pressed:
if cv2.waitKey(1) & OxFF == ord('q'):
    break
```

• When everything's done then release the capture: